

# Trudoor TDE-NL Pull Trim Installation Instructions

**NOTE:**

Backset of 2-7/16" from jamb to center or 2-3/4" from door edge to center is acceptable. Strike shim can be used or not used to make adjustments to the roller strikes projection to compensate for doors with different backsets.

