



1. Determine the mounting height of the push plate on the door. (According to the International Building Code 2018 and 2010 ADA standards, push plates shall be installed 34 inches (864 mm) minimum and 48 inches (1219 mm) maximum above the finished floor).
2. Place the push plate on the door so that the edge of plate is 1.5" [38 mm] from the edge of the door
3. Once the push plate is on the desired position, mark the door using the push plate holes as a template
4. Using a 7/64" drill bit (Hollow Metal Doors) or 1/16" drill bit (Solid Core Wood Doors), drill pilot holes through the marked spots created on step 3. (Be sure not to drill all the way through).
5. Install the push plate using the #6 x 5/8" Thread Forming Screws.